

# ROKSAN

ANALOGUE ACCESSORIES & UPGRADES


ANALOGUE

## Roksan Record Player recharging the Main Bearing with Oil

### Recharging the Main Bearing with oil

- 1 Gently pull out the Inner Platter (Avoid 'popping' it out as this could dislodge the Main Bearing ball)
- 2 Carefully clean the Main Bearing with one of the Cotton Buds (If the tip is too large and tight for the bearing, gently rub/roll the tip smaller so that it is a nice slide fit into the bearing) Push the tip all the way down and check that there is a ball impression on the tip
- 3 Remove the oil vial cap and charge the Main Bearing with 4 to 5 drops of Roksan supplied Oil (LX 7)
- 4 Use the Lint Free Tissue and gently clean the Inner Platter Spindle free from any residue oil or dirt
- 5 Gently place the Inner Platter Spindle into the Main Bearing and allow it to settle down \*

\* Due to very tight tolerances the Inner Platter will take some time to settle down



Made in England

All specifications are liable to change without prior notice. E & OE